



Zigbee config tool contains three functions:

1. Config the zigbee device through the RS232
2. Search all the device in the zigbee network
3. Upgrade the local device through the RS232

1. Open the com, click “**Load Params**”. Modify the paras , click “**Save Params**”, then “**Restart**” the device to enable the new params.




2. Click "Remote Device" on the left side, click the "Search" button, all the online zigbee device will show on the Device list except itself.




3. Upgrade the local device through the RS232

Click "Cmd/Upgrade", "Browse" the bin file from PC, open the bin file.



click the "Upgrade", then the zigbee device is upgrading...



Upgrade Success!

